
Hand Control



- A. LCD Display
- B. Microphone: Record a message for the voice alarm.
- C. LED Indicators: Indicates selection.
- D. Bed Exit: Sets low, medium, or high sensitivity.
- E. Enter: For making selection in main and sub menus.
- F. Protocol Timer: Sets 1-, 2-, or 4-hour timer.
- G. Zero: Zeroes scale and establishes base weight.
- H. Sound Level: Selects low, medium, or high volume.
- I. Up/Down Arrow Menu: Makes adjustments to menu items.
- J. Back: Press for previous menu. Press and hold for 3 seconds for home screen.



sizewise.com 800-814-9389

Rest Secure System™ Quick Reference Guide



Hand Control shown in blue; also available in green.

This card is not meant to replace product user manual. For complete manual, contact Sizewise.

800-814-9389 sizewise.com



System Setup

- 1. Plug into wall AC power.
- 2. Plug in Nurse Call interface.
- 3. Plug in Hand Control.

Zero Scale

Press and hold



button for 3 seconds.

Weighing Patient

Press



View patient weight on monitor.

System will enter standby after 60 seconds of inactivity.

To change Lbs/Kgs

Press



or



Select CHANGE LBS/KGS and press ENTER.

Select CHANGE TO LBS or CHANGE TO KGS and press ENTER.

Add Remove Items

Press



or



Select ADD/REMOVE ITEMS and press ENTER.

Press ENTER after changes are made.

See User Manual to customize time of weight history reading and alarm types/sounds.

Bed Exit Alarm

Activate Alarm

Patient must be in bed prior to activation.

Press



to select desired sensitivity setting.



High Sensitivity: Do not use high with Alternating Pressure Mattress.



Medium Sensitivity: Do not use with Rotation Therapy Mattress.



Low Sensitivity: Detects when patient has exited the bed.

Reset Alarm

Place patient back in bed. Press restart the monitoring process.



to reset the alarm and

Disable Alarm

Press and hold



for 3 seconds to silence and disable alarm.

Bed exit alarm must be reactivated after being disabled.

Protocol Timer

Set protocol reminder for 1, 2, or 4 hours.

Press



to select desired time.

To disable: Press timer button until indicator lights are off.

Adjusting Alarm Volume

Press



to select desired sound level.

NOTE: When bed exit alarm/protocol timer are disabled, the sound level indicator lights will be off.